




ON / OFF



Switch on: Push the coder 1 second
Switch off: Push the coder 3 seconds

MANUAL MODE

1 Mode

2 Temperature

3 Start



Choose Menu:
Auto / Manual / Toolbox

Select Mode:
Convection / Steam / Combi

Combi mode :
To set humidity,
press twice on

Set Temperature

Press to select preheating before cooking

Select Time / Probe Temperature

Switching button Timer / Core Temperature

Press to humidify during
cooking (Convection/Combi)

Plates Retherma-
lization mode




Set fan
speed

Open / Close
the vent

Start Hold mode or
activate it at the end
of cooking process

Press to start cooking process



CLEANING / RINSING

1 Tool box screen

2 Cleaning

4 Start

3 Intensity



Select Rinsing

Press to display cleaning
menu

Program auto cleaning

Press to Start cleaning process

Select Cleaning intensity of Light
to Intensive
The time for each is indicated on
the left

Select for new product container

CAUTION: Never use descaling product into the automatic cleaning system.

The cleaning cycle will start at the set hour each day and at the intensity selected

